


Mounting the Kodak Zi10 Camera on a Tripod

Extend the legs of the tripod > Open and place on the floor or on a classroom desktop > secure clips.

Connect the camera: Place the camera's tripod socket (found at bottom of the camera) on the screw on top of the tripod.



> Turn the knob to tightly secure the camera to the tripod



To extend the head of the tripod so it is taller (if needed): Turn knob at the base of the head to the right > Pull to extend > Turn the knob to the left to lock it

